

ORANIER


Kurzanleitung / Quick start Guide / Guide rapide

Heizen mit Holz / Heating with wood / Chauffer au bois

1.

Brennstoffwähler


Fuel selector / Sélection de combustible



2.

Sekundärluftregler Start


Secondary air control / Régulateur d'air secondaire



3.

Holz

Wood / Bois



4.

Stapeln + anzünden



Stacking + lighting / Empiler + allumer



5.

Luft drosseln


Reduce air / Réduire l'air



6.

Holz nachlegen

Stoke fire with wood / Recharger le bois



ORANIER



Kurzanleitung / Quick start Guide / Guide rapide

Heizen mit Holz / Heating with wood / Chauffer au bois

7.

Sekundärluft einstellen

Secondary air control / Ajuster l'air secondaire



0 min.

45 min.

Keine Rußspitzen
no soot / par combustion propre


8.

Beenden

End / Terminer




Off



9.

Reinigung

Cleaning / Nettoyage




1x / Tag
day
jour




2025

2026

2027



www.oranier.com



Videoanleitung



Anleitung
Manual
Manuel