

ORANIER


Kurzanleitung / Quick start Guide / Guide rapide

Heizen mit Holz / Heating with wood / Chauffer au bois

1.

Brennstoffwähler


Fuel selector / Sélection du combustion



2.

Sekundärluftregler Start


Secondary air control / Régulateur d'air secondaire



3.

Holz

Wood / Bois



4.

Stapeln + anzünden



Stacking + lighting / Empiler + allumer



5.

Luft drosseln


Reduce air / Réduire l'air



6.

Holz nachlegen

Stoke fire with wood / Recharger le bois



ORANIER


Kurzanleitung / Quick start Guide / Guide rapide

Heizen mit Holz / Heating with wood / Chauffer au bois

7.

Sekundärluft einstellen

Secondary air control / Ajuster l'air secondaire





Keine Rußspitzen
no soot / par combustion propre

8.

Beenden



End / Terminer





9.

Reinigung


Cleaning / Nettoyage



5568 Polar Neo 8 R II 2938156000



www.oranier.com



Videoanleitung