

ORANIER


Kurzanleitung / Quick start Guide / Guide rapide

Heizen mit Holz / Heating with wood / Chauffer au bois

1.

Brennstoffwähler


Fuel selector / Sélection du combustion



2.

Sekundärluftregler Start


Secondary air control / Régulateur d'air secondaire



3.

Holz


Wood / Bois



4.

Stapeln + anzünden



Stacking + lighting / Empiler + allumer



5.

Luft drosseln


Reduce air / Réduire l'air



6.

Holz nachlegen

Stoke fire with wood / Recharger le bois



ORANIER


Kurzanleitung / Quick start Guide / Guide rapide

Heizen mit Holz / Heating with wood / Chauffer au bois

7.

Sekundärluft einstellen



Secondary air control / Ajuster l'air secondaire



8.

Beenden



End / Terminer





9.

Reinigung


Cleaning / Nettoyage




7616 Polar Neo Aqua II 2938329000



Anleitung
Manual
Manuel



www.orianer.com



Videoanleitung